



## Foot Rest Lowering kit



## Installation Instructions



Photo 1

**Step 1** Install the plates as seen on photo 1. First attach the plate to the foot rest and tighten the M8 nuts. Then attach the bracket to the frame. Use the stock bolts.



Photo 2

**Step 2:** Install the gear rod spacer as seen on photo 2. Adjust the height to the desired position and fix the nut as seen on the photo2.



**Photo 3**

**Step 5:** Install brake rod spacer as seen on photo 3. Adjust the height of the brake lever and fix the top M6 nut.