

INSTALLATION INSTRUCTION



- 1. 1 pcs Plastic Hugger
- 2. 2 pcs iron DKP (D2-RH-HXADV-SET) 3. 5 pcs M6X15 Allen screws with round head
- 4. 2 pcs M5X20 Allen screws with round head
- 5. 4 pcs M6 Encased square nuts
- 6. 1 pcs Self-adhesive foam 15X10X70

The product is made of ABS plastic in glossy black color The auxiliary parts are made of 2mm DKP iron electrostatically painted in black. Silver galvanized screws and expanded EVA foam.



These are the contents you will find inside the product package as well as a card containing the link to download the leaflet with the detailed installation instructions and step-by-step rich photographic material.

Before starting the installation, read the instructions carefully so that you know if you have the right tools and skills, otherwise contact a professional.



Remove the two screws indicated by the arrows, these have two mounts that hold the rear brake pipe.

Place the Encased square nuts on the right part, as the photo shows.



Do the same on the left part.

Remove the screw that tis pointed by the arrow.



<image>

Place the right part, putting it under the base for the tube, holding everything together. As the photo shows, use the new screws and tighten it.

Stick the Self-adhesive foam 15X10X70 on the right side of the hugger as shown in the photo.

Screw the left part onto the hugger, without tighten the screws.



Place the Hugger in place. Fasten the side screw from the left.



Screw the hugger to the right part as well. Before tightening all the screws make sure the fender is in the right place. If required make adjustments before tightening all screws.



This will be your final result. Have a nice ride.



This will be the end result if you take it as well Chain guard (CG-HXADV21)