



Parts to be installed



- Step 1:** Have the bike on the centerstand or secure it on standing position.
- Step 2:** Install the brackets (C) under the headlight as seen on photo1.
Use the supplied bolts.



Step 3: Crashbars will be mounted on position I and II. See photo 2

Step 4: Install Right crashbar first. Use bolt and washer A for position I and bolt/washer/spacer B for position II. Do not fully tighten the bolts.

Step 5: Install Left crashbar. Use bolt and washer A for position I and bolt/washer/spacer B for position II. There is a rubber covering the position II thread. Carefully move the rubber out of the way when installing the spacer. Make sure that the rubber is out of the way and the spacer sits on metal frame and not on rubber. Do not fully tighten the bolts.



Step 6: Use the remaining bolt C to connect the crashbars to the brackets under the headlight.

Step 7: Tighten all bolts.