



# COSMO

motorcycle innovating products

## Centerstand NC700X-NC750X



# Installation Instructions



Photo 1



Photo 1.1

**Step 1:** Rotate the exhaust clamp as seen on photo 1 and 1.1.



**Photo 2**



**Photo 2.1**

**Step 2:** On the right side install the M8 bolt and secure it with the M8 nut as seen on the photos 2 and 2.1. The head of the M8 bolt should be 4-5mm away from the frame (photo 2). This is needed for the installation of the spring.



Photo 3

**Step 3:** Install the rubber stop on the exhaust and secure it with the M5 nut.



Photo 4



Photo 4.1



Photo 4.2

**Step 4:** Install the stand by inserting the rod on the frame (photo 4) and secure the rod with the M6 nut (photo 4.1).



**Step 5:** Install the spring. The long hook should go on the M8 of photo 2 and the short hook should be on the centerstand hook.