

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED:

- Socket wrench N10
- Allen key N4
- Allen key N5

Installation Steps:

1. Unscrew the two M6 nuts located under the seat saddle.
2. Hold the backrest in your hands and screw in the two spacers on the side with the male base. Once fully tightened, turn the spacers half a turn backwards so the heads of the screws face outward and are visible.
3. Place the backrest with the spacers onto the mounting point on your seat and fasten it from underneath using 2 Allen bolts with their washers.
4. Adjust the backrest from both sides to the desired position and tighten the screws.